# HOW TO MEASURE FOR TIER-ON-TIER WITH T-BAR



### What is Tier on Tier with T-Bar?

A Tier on Tier shutter with a fixed horizontal T-Post positioned at the divide point.

It provides additional support for the top tier panels when closed and can also make installation simpler.


#### What size is the T-Bar?

The T-Bar is a standard size: Back Width = 57mm Front Width = 25mm Depth = 50mm



Ensure you allow sufficient clearance for any obstructions e.g. handles.

The T-Bar will be fitted with magnet strike plates to help keep the panels closed.





## How to measure for the T-Bar

Simply measure from the bottom on the shutter (usually the sill or floor) up to where you'd like the T-Bar to be <u>centred</u>.

If the window has a transom we recommend measuring to the centre point for uniformity.

#### How to order Tier on Tier with T-Bar

From 01/12/20 this style can be ordered by selecting standard 'Tier on Tier' and by entering a special note for each applicable line: "Tier on Tier with T-Bar". There is no surcharge for this style.

The T-Bar location should be entered in the 'Divide point' field (Step 4 Panels & Slats)

Divide point (mm) 70	)
----------------------	---

Note: Tier on Tier with T-Bar will be added to the portal as a selectable style option - COMING SOON.